


REGOLAZIONE VOLUME
 ALTOPARLANTE
 REGLAGE VOLUME HAUT
 PARLEURADJUSTMENT SPEAKER
 VOLUME
 REGOLAZIONE VOLUME
 MICROFONO
 REGLAGE VOLUME
 MICROPHONEADJUSTMENT
 MICROPHONE

**AUDIO VIDEO
 CHANGE OVER
 SWITCH 10030**

11 AC IN	RELAY N.O. AUDIO 10
12 DC - IN	SWITCH AUDIO 9
13 GROUND 0V IN	RELAY N.C. AUDIO 8
	SWITCH VIDEO 7
	RELAY N.C. VIDEO 6
	RELAY N.O. VIDEO 5
	NOT USED 4
	NOT USED 3
	GROUND 0V 2
	NOT CONNECTED 1

14 TRG 2
15 TRG 1



2122x, 2123x & 10030
 _10143 (1n4007)

acet

2 WIRES DOOR-PHONE SYSTEM
 WITH 2 ENTRANCE WITH
 AUTOMATIC COMMUTATION.
 DUAL TONE CALL CALL